

High precision fluxgate AC/DC current transducer for galvanically isolated measurement up to 370 A

Features

- 200 A rms nominal current
- 500:1 primary/secondary current ratio
- Current output through D-sub-9 connector
- Ø27.6 mm aperture
- 16 ppm total accuracy
- 1 ppm linearity
- · 15 ppm offset
- 1 MHz bandwidth (±1 dB)
- Status signal and LED





Description

High precision DC current transducer (DCCT) measuring up to 370 A currents and continuously measuring 300 A currents with a linearity error less than 1 ppm.

Based on the ultra stable Danisense closed loop flux gate technology, the DS200ID has very low offset and ultra low drift.

It provides high resolution for precise monitoring, reliable and consistent performance, and a rugged design for durability.

Applications

- Electric vehicle (EV) test bench
- Power measurement and power analysis
- · Particle accelerators
- · MRI devices and medical scanners
- · Battery testing and evaluation systems
- · Current calibration purposes
- · Stable power supplies
- · Precision current sensing



Electrical specifications at 23 °C, V_S = \pm 15 V supply voltage

| Parameter | | Symbol | Unit | Min | Тур. | Max | Comment |
|---|--------------------|--------------------|-----------|-----------|-------------|------------|--|
| Nominal primary AC current | Continuous | I _{PN AC} | Arms | | | 200 | See Fig. 3 for details |
| Nominal primary DC current | Continuous | I _{PN DC} | Α | -300 | | 300 | For other values see Fig. 2 |
| Measuring range | | I _{PM} | Α | -370 | | 370 | See Fig. 2 & Fig. 3 for details |
| Overload capacity | Peak | I _{OL} | Α | | | 1500 | Single pulse 100ms |
| Nominal secondary current | Continuous | I _{SN} | mA | -600 | | 600 | At nominal primary DC current |
| Primary / secondary ratio | | | | 500 | | 500 | I _{primary} /I _{secondary} |
| Measuring resistance | | R _M | Ω | 0 | 2.5 | | See Fig. 2 for details |
| Linearity error | | ϵ_{L} | ppm | -1 | | 1 | ppm refers to reading |
| Offset current (including earth | field) | I _{OE} | ppm | 15 | | 15 | ppm refers to I _{PN DC} |
| Offset temperature coefficient | | TC _{IOE} | ppm/K | -0.1 | | 0.1 | ppm refers to I _{PN DC} |
| Offset stability over time | | | ppm/month | -0.1 | | 0.1 | ppm refers to I _{PN DC} |
| Bandwidth | | f(±1dB) | kHz | | 1000 | | Small signal. See Fig. 4 |
| Response time to a step currer | it I _{PN} | t _r | μs | | 1 | | To 90% of step current |
| Total accuracy without offset | | ϵ_{tot} | | % of read | ling + % of | full scale | Full scale refers to I _{PN DC} . |
| | <10 Hz | | | 0.00 | 002 + 0.00 | 0001 | For details, see Reading and full |
| | <100 Hz | | | 0.00 | 004 + 0.00 | 0003 | scale |
| | <1 kHz | | | 0.0 | 02 + 0.000 | 005 | For other frequencies, see Linear |
| | <10 kHz | | | 0 | .2 + 0.000 |)1 | interpolation of accuracy |
| | <100 kHz | | | | 0.5 + 0.002 | 2 | specification. |
| | <1000 kHz | | | | 10 + 0.01 | | |
| Phase shift | <10 Hz | | | | 0.01° | | |
| | <100 Hz | | | | 0.01° | | |
| | <1 kHz | | | | 0.02° | | |
| | <10 kHz | | | | 0.3° | | |
| | <100 kHz | | | | 1° | | |
| | <1000 kHz | | | | 15° | | |
| RMS noise | <10 Hz | | ppm rms | | | 0.01 | ppm refers to I _{PN DC} |
| | <100 Hz | | | | | 0.05 | |
| | <1 kHz | | | | | 0.1 | |
| | <10 kHz | | | | | 0.2 | |
| | <100 kHz | | | | | 4 | |
| Peak-to-peak noise | <10 Hz | | ppm p-p | | | 0.05 | ppm refers to I _{PN DC} |
| | <100 Hz | | | | | 0.25 | |
| | <1 kHz | | | | | 0.5 | |
| | <10 kHz | | | | | 1 | |
| | <100 kHz | | | | | 20 | |
| Fluxgate excitation frequency | | f _{exc} | kHz | | 31.25 | | |
| Power supply voltages | | Vs | V | ±14.25 | | ±15.75 | |
| Idle current consumption | | | mA | | ±100 | | Primary current = 0 A |
| Current consumption at nominal current | | | mA | -700 | | 700 | At I _{PN DC} |
| Current consumption at max current | | | mA | -840 | | 840 | At I _{PM} |
| Operating temperature range | | Ta | °C | -40 | | 85 | See Fig. 3 |
| Offset change with external ma | ignetic field | | ppm/mT | | ±10 | | ppm refers to nominal current |
| Offset change with power supply voltage changes | | | ppm/V | -0.3 | | 0.3 | ppm refers to nominal current |

¹ ppm nominal = 0.6 μ A secondary current.



Linearity error

Linearity error is defined as the deviation from a straight line. The straight line is a linear regression trend line based on the least squares method of the measurement points from 0 to positive max current and another trendline is calculated from 0 to negative max current. The difference between each measured point and the linear trend line is the linearity error. The linearity error ϵ_L can be expressed as (1), where $I_{reading}$ is the measurement result and I_{fitted} is the regression value.

$$\epsilon_{L} = I_{\text{reading}} - I_{\text{fitted}}$$
 (1)




Figure 1: Linearity error definition

Reading and full scale

Reading is the actual value measured at a given time. Full scale is the rated nominal value of the device. If a given current $I_{reading}$ is measured, the total accuracy is calculated as (2). Example: A 500 A rated device has a specification of 0.005% + 0.0015% (reading + full scale) at < 10 Hz, plus an offset of 0.001% (of full scale). The device is measuring (reading) 10 A dc, and the accuracy is calculated as (3).

$$\epsilon_{\mathrm{tot}} = \epsilon_{\mathrm{reading}} \cdot I_{\mathrm{reading}} + (\epsilon_{\mathrm{fullscale}} + \epsilon_{\mathrm{offset}}) \cdot I_{\mathrm{PNDC}}$$
 (2)

$$\epsilon_{\text{tot}} = 0.005\% \cdot 10\text{A} + (0.0015\% + 0.001\%) \cdot 500\text{A} = 13\text{mA}$$
 (3)

Primary and secondary current/voltage

The secondary current I_S or voltage V_S is calculated by using the transfer ratio k, as in (4).

$$I_{S} = \frac{I_{P}}{k}, \qquad V_{S} = \frac{I_{P}}{k} \tag{4}$$

Converting from ppm of nominal to secondary current/voltage

The nominal primary current is the rated current for the device. If ϵ_{ppm} is the error in ppm referred to nominal, use (5) to convert to ampere primary current. If the primary/secondary transfer ratio is k, use (6) to convert to ampere secondary current. If the device has voltage output, use (7)

$$\epsilon_{\mathsf{P}_{\mathsf{ampere}}} = \epsilon_{\mathsf{ppm}} \cdot \mathsf{I}_{\mathsf{PNDC}} \cdot 1 \times 10^{-6}$$
 (5)

$$\epsilon_{\text{S}_{\text{Ampere}}} = \epsilon_{\text{ppm}} \cdot \frac{I_{\text{PNDC}}}{k} \cdot 1 \times 10^{-6}$$
 (6)

$$\epsilon_{\text{S}_{\text{volt}}} = \epsilon_{\text{ppm}} \cdot \frac{I_{\text{PNDC}}}{k} \cdot 1 \times 10^{-6}$$
 (7)

Linear interpolation of accuracy specification

If the accuracy at a specific frequency is required, it is possible to use linear interpolation between known points. If the frequency f is $f_1 < f < f_2$ and the accuracy at the frequency $\epsilon(f)$ is $\epsilon(f_1) < \epsilon(f) < \epsilon(f_2)$, then the accuracy at f is found as (8).

$$\epsilon(\mathbf{f}) = \frac{\epsilon(\mathbf{f}_2) - \epsilon(\mathbf{f}_1)}{\mathbf{f}_2 - \mathbf{f}_1} (\mathbf{f} - \mathbf{f}_1) + \epsilon(\mathbf{f}_1)$$
(8)




Figure 2: Maximum measurement resistor $R_{\mbox{\scriptsize M}}$ vs. ambient temperatures




Figure 3: Maximum continuous primary current vs. frequency




Figure 4: Frequency characteristics



Isolation specifications according to IEC 61010-1



When using *REINFORCED insulated* wire, all wiring must be insulated for the highest voltage used. When using *BASIC insulated* or *uninsulated* wire, follow the specified voltages in the table below:

| Parameter | | Unit | Value |
|---|----------------------|-------|-------|
| Clearance | | mm | 9.5 |
| Creepage distance | | mm | 10.5 |
| Comparative tracking index (CTI) | | | > 600 |
| Continuous working voltage according to IEC 61 | 1010-1 with: | | |
| Uninsulated wire: | Non mains | | 1000 |
| | CAT II (dc and rms) | | 600 |
| | CAT III (dc and rms) | \ \ \ | 300 |
| BASIC insulated wire: | Non mains | V | 2000 |
| | CAT II (dc and rms) | | 1000 |
| | CAT III (dc and rms) | | 1000 |
| Transient voltage according to IEC 61010-1 with | : | | |
| Uninsulated wire: | Non mains | | 4500 |
| | CAT II | | 6000 |
| | CAT III | ., | 6000 |
| BASIC insulated wire: | Non mains | V | 6500 |
| | CAT II | | 6000 |
| | CAT III | | 8000 |



Do not connect the transducer to signals or use for measurements within Measurement Category IV, or for measurements on MAINs circuits or on circuits derived from Overvoltage Category IV which may have transient overvoltages above what the product can withstand. The product must not be connected to circuits that have a maximum voltage above the continuous working voltage, relative to earth or to other channels, or this could damage and defeat the insulation.

Environmental and mechanical characteristics

| Parameter | Unit | Min | Тур | Max | Comment |
|-----------------------------|------|-----|-----|------|-------------------------|
| Altitude | m | | | 2000 | |
| Usage | | | | | Designed for indoor use |
| Pollution degree | | | | 2 | |
| Operating temperature range | °C | -40 | | 85 | |
| Storage temperature range | °C | -40 | | 85 | |
| Relative humidity | % | 20 | | 80 | Non-condensing |
| Ingress protection rating | | | | IP20 | |
| Mass | kg | | 0.6 | | |

Connections: D-sub-9

EMC: EN 61326-1:2013-2021

Safety: IEC 61010-2-030:2021/A11:2021 and IEC 61010-1:2010/A1:2019



External devices: External devices connected to current transducers must comply with the standards

IEC61010-1 and IEC62368-1 and be energy-limited circuitry

Cleaning: The transducer should only be cleaned with a damp cloth. No detergent or

chemicals should be used.

Temperature: When multiple primary turns are used or high primary currents are applied the

temperature around the transducer will increase, please monitor to ensure that the maximum ratings are not exceeded. It is recommended to have minimum 1

 $\,\mathrm{mm}^2$ per ampere in the primary bus bar.

Intended use

The DS200ID is designed to measure current up to 370 A, and be powered by a DSSIU-4-1U or DSSIU-6-1U or similar power supplies. Please see the product manual: https://danisense.com/user-manual.

Instruction for use



Please follow the polarity of the voltage supply to avoid damaging the device. See Fig. 7.

- 1. Do not power up the device before all cables are connected.
- 2. Place the primary conductor through the aperture of the transducer.
- 3. Connect a D-sub-9 cable between DSSIU-4/6-1U and each sensor.
- 4. Connect a low impedance amperemeter, measuring resistor or power analyzer on the secondary output (4mm red and black connectors on the DSSIU-4/6-1U).
- 5. When all connection are secured connect mains power.
- 6. Apply primary current.



There is a risk of electrical shock if an uninsulated busbar with high voltages is touching the metal en- closure of the transducer. Please ensure, before powering up the system, that no uninsulated wire can touch the metal enclosure.

Advanced Sensor Protection Circuits "ASPC"

Developed to protect the current transducer from typical fault conditions:

- · Unit is un-powered and secondary circuit is open or closed
- · Unit is powered and secondary circuit is open or interrupted

Both DC and AC primary current up to 100% of nominal value can be applied to the current transducers in the above situations without damage to the electronics. Please notice that the transducer core can be magnetized in all above cases, leading to a small change in output offset current (less than 10ppm)



Do not disassemble the unit. If the green status LED is not operating with all cables connected and the system powered up, disconnect power and contact Danisense for further instruction. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.






Figure 5: Dimensions of sensor head. Tolerance is 0.3 mm

Mounting

Base plate: 2 x M5 holes, 6 Nm

Back side: 3 x M4 threaded holes, 4 Nm



Figure 6: External measurement resistor connection, see

Fig. 2

Positive current direction

Is identified by an arrow on the back side isolation plastic insert.

Pin out description




Figure 7: D-sub-9 connection pinout

| 1 | Out- | Measurement output negative terminal |
|---|------------------|--------------------------------------|
| 2 | NC | No connection |
| 3 | Status- | Status signal negative terminal |
| 4 | 0 V | 0 V connection for supply voltage |
| 5 | V _S - | Negative supply voltage |
| 6 | Out+ | Measurement output positive terminal |
| 7 | NC | No connection |
| 8 | Status+ | Status signal positive terminal |
| 9 | V _S + | Positive supply voltage |



Status signal and LED




Figure 8: Status signal optocoupler

When the sensor is operating in normal condition the status pins (Status+ and Status-) are shorted by an optocoupler and the green status LED is ON, see Fig. 8. When a fault is detected, or the power is off, the status pins are opened and the green status LED is OFF. Status signal optocoupler ratings found below:

| Forward direction: | Status+ to Status- (Pin 8 to pin 3) |
|--------------------------|-------------------------------------|
| Maximum forward current: | 10 mA |
| Maximum forward voltage: | 60 V |
| Maximum reverse voltage: | 5 V |



Declaration of Conformity

Danisense A/S Malervej 10 DK-2630 Taastrup Denmark

Declares that under our sole responsibility that this product is in conformity with the provisions of the following EC Directives, including all amendments, and with national legislation implementing these directives:

<u>Directive 2014/30/EU</u> Directive 2014/35/EU

And that the following harmonized standards have been applied

EEN 61010-1 (Third Edition):2010, EN 61010-1:2010/A1:2019

EN 61010-2-030:2021/A11:2021

EN 61326-1:2013

All DANISENSE products are manufactured in accordance with RoHS directive 2011/65/EU. Annex II of the RoHS directive was amended by directive 2015/863 in force since 2015, expanding the list of 6 restricted substances (Lead, Hexavalent Chromium, PBB, PBDE and Cadmium)

Danisense follows the provision in EN 63000:2018

Place

Taastrup, Denmark

Date

Henrik Elbæk

Hourl Effe

2022-03-15